# CE 3305 Fluid Mechanics; Spring 2014 Quiz 5

1. A bubbler gage is a device that determines the surface level of a liquid by discharging a small amount of gas through a small tube, one end is submerged in the liquid, and a pressure gage is tapped into the tube to measure pressure of the gas.

If the pressure on the gage in Figure 1 is 15 kPa, what is the depth of the liquid d in the figure?




Figure 1: Sketch of bubbler in a tank. Notice the liquid is at S.G.=0.8

# KNOWN:


$$pg = 0.8(9800 \text{ N/m}^3) = 7840 \text{ N/m}^3$$
  
P=15 kN

# GOVERNING EQUATION:

#### UNKNOWN:

d

# SKETCH:



# SOLUTION:

$$d=1m+h$$
 $P=pgh$ 
 $\therefore h=P=\frac{15,000 \text{ N/m}^2}{0.8(9800 \text{ N/m}^3)}=1.91 \text{ meters}$ 
 $d=h+1=1.91+1=2.91 \text{ meters}$